

# Marshall

MID ACTIVE NOISE CANCELLING – ON EAR


USER MANUAL



## CONTENTS

### LANGUAGES

ENGLISH .....	002.	KOREAN – 한국어 .....	020.
ARABIC – العربية .....	003.	LATVIAN – LATVIEŠU .....	021.
BULGARIAN – БЪЛГАРСКИ ЕЗИК .....	004.	LITHUANIAN – LIETUVIŲ .....	022.
CROATIAN – HRVATSKI .....	005.	NORWEGIAN – NORSK .....	023.
CZECH – ČEŠTINA .....	006.	POLISH – POLSKI .....	024.
DANISH – DANSK .....	007.	PORTUGUESE – PORTUGUÊS .....	025.
DUTCH – NEDERLANDS .....	008.	ROMANIAN – ROMÂNĂ .....	026.
ESTONIAN – EESTI .....	009.	RUSSIAN – РУССКИЙ .....	027.
FILIPINO – WIKANG FILIPINO .....	010.	SIMPLIFIED CHINESE – 简体中文 .....	028.
FINNISH – SUOMI .....	011.	SLOVAK – SLOVENČINA .....	029.
FRENCH – FRANÇAIS .....	012.	SLOVENE – SLOVENŠČINA .....	030.
GERMAN – DEUTSCH .....	013.	SPANISH – ESPAÑOL .....	031.
GREEK – ΕΛΛΗΝΙΚΑ .....	014.	SWEDISH – SVENSKA .....	032.
HEBREW – עברית .....	015.	THAI – ไทย .....	033.
HUNGARIAN – MAGYAR .....	016.	TRADITIONAL CHINESE – 繁體中文 .....	034.
INDONESIAN – BAHASA INDONESIA .....	017.	TURKISH – TÜRKÇE .....	035.
ITALIAN – ITALIANO .....	018.	UKRAINIAN – УКРАЇНСЬКА .....	036.
JAPANESE – 日本語 .....	019.	VIETNAMESE – TIẾNG VIỆT NAM .....	037.



## DEVICE LAYOUT

### 1 CONTROL KNOB

- I. **BLUETOOTH ON/OFF**  
PUSH AND HOLD FOR 3 SECONDS
- II. **PLAY/PAUSE**  
SINGLE-CLICK
- III. **NEXT SONG**  
PUSH TO THE RIGHT
- IV. **PREVIOUS SONG**  
PUSH TO THE LEFT
- V. **FAST FORWARD**  
PUSH TO THE RIGHT AND HOLD
- VI. **REWIND**  
PUSH TO THE LEFT AND HOLD
- VII. **TURN UP THE VOLUME**  
PUSH UPWARDS
- VIII. **TURN DOWN THE VOLUME**  
PUSH DOWNWARDS
- IX. **HANDLE CALLS**
  - SINGLE-CLICK TO ANSWER OR END CALL
  - DOUBLE-CLICK TO REJECT AN INCOMING CALL
- X. **ACTIVATE/STOP SIRI\***  
DOUBLE-CLICK

### 2 ANC ON/OFF SWITCH

TURN ON THE ACTIVE NOISE CANCELLATION TO REDUCE THE BUZZ AND NOISES OF YOUR SURROUNDINGS. ANC CAN BE USED WHILE LISTENING TO MUSIC OR WITH BLUETOOTH OFF FOR SOME PEACE AND QUIET.

- I. **ANC ON**
- II. **ANC OFF**

NOTE: MAKE SURE THAT ANC IS SET TO OFF WHEN NOT USING THE HEADPHONES TO CONSERVE BATTERY POWER.

### 3 LED INDICATOR

- I. **CHARGING**
- II. **FULLY CHARGED**
- III. **AUDIO PAUSED**
- IV. **BLUETOOTH® PAIRING MODE**
- V. **BLUETOOTH OFF OR PLAYING**

### 4 3.5 mm INPUT/OUTPUT SOCKET

SHARE YOUR AUDIO BY PLUGGING IN ANOTHER PAIR OF HEADPHONES INTO THE 3.5 mm SOCKET.

IF YOU ARE LOW ON POWER, SIMPLY USE THE DOUBLE ENDED 3.5 mm CORD WITH BUILT-IN REMOTE AND MICROPHONE.

- SINGLE-CLICK TO PLAY, PAUSE, ANSWER CALLS OR HANG UP.
- DOUBLE-CLICK FOR NEXT SONG OR TO REJECT CALLS.
- TRIPLE-CLICK FOR PREVIOUS SONG.

### 5 USB PORT FOR CHARGING BATTERY

WHEN THERE IS LESS THAN 1 HOUR OF CHARGE, A BATTERY LOW ALERT WILL SOUND. PLUG YOUR HEADPHONES TO A USB POWER SOURCE VIA THE MICRO USB CABLE TO CHARGE THE BATTERY.

A FULL BATTERY RECHARGE TAKES APPROXIMATELY 3 HOURS.

### 6 REMOVABLE EAR CUSHIONS

HOLD THE EAR CAP AND TURN IT COUNTER-CLOCKWISE.

### OPERATING TIME

- ANC ONLY ..... 30+ HOURS
- BLUETOOTH ONLY ..... 30+ HOURS
- BLUETOOTH AND ANC ..... 20 HOURS

THE OPERATING TIME IS CALCULATED USING RANDOM SELECTED MUSIC PLAYED AT MEDIUM VOLUME.

### GETTING STARTED

01. PUSH AND HOLD THE CONTROL KNOB FOR 5 SECONDS UNTIL THE LED BLINKS BLUE.
02. SELECT **MID ANC** FROM YOUR SOUND DEVICE'S BLUETOOTH® LIST. THE INDICATOR TURNS OFF WHEN PAIRING IS COMPLETE.
03. PRESS PLAY, AND ENJOY YOUR NEW HEADPHONES

IT IS RECOMMENDED TO CHARGE THE BATTERY BEFORE USING YOUR HEADPHONES FOR THE FIRST TIME.

\*Siri is supported when paired with an iOS or macOS device.