

Congratulations on your purchase from RocknRoller Multi-Cart, the most acclaimed and innovative transforming utility carts available. Although very easy to use, RocknRoller Multi-Cart's patented design operates differently than typical carts or dollies. To ensure maximum performance from your RocknRoller Multi-Cart, we recommend reading this instruction and assembly sheet thoroughly. U.S. Patent #'s: 5,228,716; 5,476,282; 6,966,574; 7,437,801; 7,490,847 & Pats. Pend.


**LIMITED WARRANTY:** RocknRoller Multi-Carts carry a one year limited warranty against defective material or workmanship on basic frame and components. Casters and wheels carry a 60 day warranty against defects. As with any equipment, normal maintenance is required. Caution should be used when moving any load with Multi-Carts or any other dolly.

R12RT Model Specifications		
Length (Compact)	34"	
Length (Extended)	52"	
Width (Frame Bed)	13.5"	
Width (Rear)	20"	
Height (Folded)	12"	
Height (Unfolded)	41.5"	
Front Casters	8" x2.5"	
Rear Wheels	10" x 3"	
Weight	33 lbs.	
Load Capacity	500 lbs.	


Your RocknRoller Multi-Cart shipping box should contain a frame and the following parts:	
1 x	1" (25 mm) square plastic endplugs
1 x	¾" (20 mm) square plastic endplugs
2 x	¹/8" x 1 ¼" cotter pins
2 x	¹/8" x ¾" cotter pins
2 x	35 mm rivet pin
2 x	20 mm flat washer
2 x	10"x 3" (250 mm x 75 mm) wheels
2 x	8"x 2" (200 mm x 51 mm) rear wheels
1 x	Assembly/instruction sheet
2 x	705 mm Non-skid Tape

## **Assembly Instructions**

**Caution:** Be careful to not pinch or strike fingers during assembly. Be careful of metal burrs inside tubing.



Gently slide wheel over axle as shown. Do not force wheels onto axle. It is recommended to lubricate axles with light grease before installing. Install cotter pins and bend ends outward.



Carefully insert caster stem into receptor tube and line up caster stem holes with the receptor tube holes. Stem should fit very snugly in receptor tube. Install cotter pins and bend ends outward.



**Customer Service & Technical Support** 

## Operating your Rock N Roller® Multi-Cart® Multi-Carts instantly transform into any of 8 different configurations

Caution: When loading equipment on a hill or incline, set brake. (Block wheels if load is very heavy). Caution should be used when moving any load with Multi-Carts or any other dolly. Over rough terrain it is recommended to push cart with the large wheels forward.



## Extending Frame Raising Foldable Sides



Loosen wingbolts 1/4 turn. Step on rear axle and push in extension stop button. Pull up on frame as shown until stop button engages. Retighten wingbolts.



Firmly press down on release cable while raising other end of foldable side as shown.

Repeat with other side.

- 1. **SHORT FURNITURE DOLLY:** Place cart on all four wheels with sides folded down as shown. When using Multi-Cart in extended 4-wheel dolly configuration, distribute load evenly over frame bed when possible, placing the heaviest items over the large rear wheels to make rolling easier.
- 2. **LONG NOSE LUGGAGE CART:** Extend cart into 4-wheel hi-stacker mode. Set on one end as shown, pull top release cable and lower top foldable side.
- 3. **STORAGE-TRANSPORT:** With sides upright, place cart on end, loosen wingbolts under frame 1/4 turn, push in extension stop button, and push down to compact cart to minimum length. Retighten wingbolts. Place cart on all 4 wheels. FOLD HANDLES IN THIS ORDER: 1st, push down release cable over large wheels with one hand and fold down side with the other hand. 2nd, fold side over front swivel casters in the same manner. Cart will not fold down correctly unless done in this order. Stand cart on end to store or place upside down to ride in vehicles or on airport conveyor belts.
- 4. **SHORT PLATFORM CART:** Firmly push down on release cable located over swivel casters with one hand while raising the foldable side with the other hand until side locks into place in upright position.
- 5. **SHORT HI-STACKER:** Raise both sides as previously described.
- 6. **LONG PLATFORM CART:** Take short hi-stacker configuration and set on 2 large wheels (upright). Loosen 2 wingbolts 1/4 turn and pull frame upward until button engages. Retighten wingbolts and set cart back on all 4 wheels.
- 7. **LONG HI-STACKER:** Raise folded handle of long platform cart.
- 8. LONG PLATFORM CART: From long hi-stacker configuration, fold down side over large wheels first, then fold down side over swivel casters.

## RocknRoller® Multi-Cart® R12RT Accessories





Customer Service & Technical Support