# Cleaning and Maintenance:

- 1. The HideAway fascia can be cleaned with a mild detergent, water and a soft cloth to wash off any marks. Rinse and dry with a clean cloth or towel.
- 2. Refer to your Grandview Motorised Screen Instructions for details on cleaning your screen surface.

Warranty: 12 Months


**Happy Viewing!** 

Imported and distributed in Australia by



ambertech.com.au amber.co.nz

# HIDEAWAY USER MANUAL




**MODELS:** HH3 / HH4 / HH5 / HH6 / HH7



# Congratulations on purchasing a HideAway





# Step 1

You will need a cutout in your ceiling - depending on the size of your HideAway (double check the size first, see table below)

## Step 2

The side of the box marked "Viewing Side" faces the projector.

# Step 3

The mounting brackets for the HideAway box are secured at both ends for easy installation.

# Step 4

Hang the HideAway so that the Aluminium Trim is flush with the underside of the ceiling.

# Step 5

When you have secured the HideAway box on the ceiling, open the access panel and hang your Grandview Screen on the brackets supplied inside.

# Step 6

### **Cable Access**

Grandview screens have the cable exit on the left-hand side of the screen (from the viewing side). You will need to drill new access holes on this side.

### **Trim Slot** Product External Box Trim Flange **Shipping Size** Gross To Suit Grandview IP Screens Code W x D x H (mm) W x D (mm) LxW (mm) LxWxH(mm) Weight (Kg) HH3 2560 x 220 x 160 2604 x 266 2400 x 50 2900 x 380 x 260 51 GRIP084V, GRIP100V, GRIP085H, GRIP092H, GRIP095H, GRIP094C, GRIP103C HH4 2975 x 220 x 160 3019 x 266 2815 x 50 3250 x 430 x 270 62 GRIP120V, GRIP102H, GRIP112H, GRIP110C 3360 x 295 x 250 3200 x 90 3600 x 450 x 270 85 HH5 3406 x 340 GRIP120H, GRIP130H, GRIP120C, GRIP130C HH6 3750 x 300 x 250 3796 x 346 3590 x 90 3880 x 455 x 285 93 GRIP140H, GRIP150V, GRIP140C, GRIP150C, GRIP150H HH7 5006 x 303 x 250 5066 x 366 4750 x 90 5155 x 470 x 290 155 GRIP180V, GRIP160H, GRIP180H, GRIP200H, GRIP180C, GRIP200C

# Step 7

### **Testing**

Check the screen travels freely through the slot and doesn't catch. If out of alignment you may need to insert a spacer.

# Step 8

Follow the instructions supplied with your screen for the correct wiring diagram.

# Step 9

Test that the screen operates correctly, and set the limits, if required. Follow the instructions supplied with your screen to do this.

# Step 10

Screen should always retract to the Upper Limit previously set by the factory as the default position. The fabric should not be exposed when in the closed position.